

STATIC CLING & DECAL WET MOUNT APPLICATION INSTRUCTIONS

Things You Will Need: Window Cleaner • Paper Towels • Squeegee/Credit Card

Fast and Easy Application

Step

- 1 Thoroughly clean the window area to which you will apply the window cling/decal. Use window cleaner and a towel or sponge. Dry the window completely to ensure no dust remains which could cause “pimples” or air bubbles in the cling.

Step

- 2 Lay the window cling on a flat surface with the side to be applied to the window facing up. Peel the paper backing. Spray the exposed side with the window cleaner until completely covered. Spray the window area liberally where you will place the cling and leave wet.

Step

- 3 Place the wet side against the window where you would like to apply the cling. The cling should be able to slide easily on the window. Position to the desired location.

Step

4 Starting at the center of the window cling/decal, squeegee the excess water out toward the edges until all the moisture has been forced out. Dry the edges carefully with a paper towel by dabbing without damaging the edges. Cling should be dry within a few hours and fully cured in 24 to 48 hours.

****Must Be Applied At Temperatures No Less Than 55°****